


Installation Instruction



Fits most monitor size: 13"-27"

Load weight: 3.3~15.4 lbs (1.5~7 kg)

VESA: 75 x 75 and 100 x 100

UNPACKING INSTRUCTIONS

- Carefully open the carton, remove contents and lay out on cardboard or other protective surface to avoid damage.
- Check package contents against the Supplied Parts List in the next page to assure that all components were received undamaged. Do not use damaged or defective parts.
- Carefully read all instructions before attempting installation.

IMPORTANT SAFETY INFORMATION

- Install and operate this device with care. Please read this instruction before installation, and carefully follow all instructions contained herein. Use proper safety equipment during installation.
- Please call a qualified installation contractor for help if you don't understand these directions or have any doubts about the safety of the installation.

Do not use this product for any purpose or in any configuration not explicitly specified in this instruction. We hereby disclaims any and all liability for injury or damage arising from incorrect assembly, incorrect mounting, or incorrect use of this product.

The diagram illustrates the four steps for attaching the upper part of the cabinet to the wall:

- 3.1**: Shows the upper hinge being inserted into the pre-drilled hole in the wall.
- 3.2**: Shows the upper hinge being secured with a screw.
- 3.3**: Shows the upper hinge being secured with a second screw.
- 3.4**: Shows the upper hinge being secured with a third screw.